

Gemini PVC

Installation Guide Lines

Allow Gemini PVC to acclimatise in situ 24 hours prior to installation, insuring a working ambient temperature of 18 o Celsius

Good surface preparation is essential for a successful installation. All existing wall finishes should be removed below the capping line.

The vertical structure should be free of any adhesive residues or contaminants, it should be dry (test walls for damp if in doubt), smooth, dust free & structurally sound.

Vertical wall finishes should meet with the subfloor, paying particular attention to external/internal corners

Gemini PVC should not be installed over existing floor coverings or linings.

Gemini PVC Cove Former

(Guide lines are the same to floors as walls, see above.)

1. Lay sufficient cove former face down on disposable protection ensuring no overspray on finished subfloor.
2. Apply Gemini Gold Spray Adhesive to the wall at the required height and to the back of the cove former, allowing the adhesive to become touch dry. External mitres should be cut using a hacksaw and mitre block, internal mitres can be butt fitted ensuring one section is scribed to the other, this allows for extra support to mitred finished floor coverings.
3. Introduce the cove former to the wall where it meets the subfloor, apply even pressure to the full length of the cove ensuring full contact is made.